
KYOCERA

kyoceradocumentsolutions.com

Maintenance Menu User Guide

2023.08
MMUGKDEN



Legal notes

Unauthorized reproduction of all or part of this guide is prohibited.

The information in this guide is subject to change without notice.

We cannot be held liable for any problems arising from the use of this product, regardless of the information herein.

Regarding trademarks

Microsoft®, Windows®, and Active Directory® are registered trademarks of Microsoft Corporation in the U.S. and/or other countries.

All other brand and product names herein are registered trademarks or trademarks of their respective companies.

Table of Contents

Chapter 1 Product overview

Documentation..... 1-1
Conventions..... 1-1
System requirements..... 1-2

Chapter 2 Using the application

Chapter 3 Maintenance Menu options

1 Product overview

Maintenance Menu is an application that is available in the Product Library disc or from a printer driver installer package that can be downloaded from the KYOCERA Document Solutions website. To use this application, you must have a supported printer driver installed on your computer. With this application, you can do any of the following:

- Adjust print or scan positions
- Control print quality with drum charge or altitude settings
- Load and use maintenance package files

Some features and options may not be available to your printer.

Documentation

This guide helps you understand and use the options available in Maintenance Menu.

This guide is intended for advanced printer users and system administrators.

Conventions

The following conventions may be used in this guide:

- **Bold text** is used for menu items and buttons
- Screen, text box, and drop-down menu titles are spelled and punctuated exactly as they are displayed on the screen
- *Italics* are used for document titles
- Text or commands that a user enters are displayed as text in a different font or in a text box as shown in these examples:

1. On the command line, enter `net stop program`
2. Create a batch file that includes these commands:

```
net stop program
gbak -rep -user PROGRAMLOG.FBK
```

- Icons are used to draw your attention to certain pieces of information. Examples:

This indicates information that is useful to know.

This indicates important information that you should know, including such things as data loss if the procedure is not done properly.

System requirements

Refer to the *Release Notes* or *ReadMe* that accompany this product.

2 Using the application

Make sure that your printer and computer are turned on and connected by USB, network, or parallel cable. Parallel connection is available only in some printers.

1 Run the installer.

Method	Steps
Product Library installer	**a.** Insert the printer Product Library disc into the drive. If necessary, select `Setup.exe`. **b.** Run the installer. If necessary, allow the installer to make changes to your computer. **c.** Read and accept the license agreement. **d.** In Product Library, select **Maintenance** > **Maintenance Menu** > **Run**.
Standalone installer	**a.** From a web browser, go to https://kyocera.info. **b.** Select your printer, operating system, and language. **c.** In Utility, go to Maintenance Menu, then select the download button. Maintenance Menu is available only in Utility if your printer is supported by the application. **d.** To begin the download, read and accept the license agreement. Take note of the download location. **e.** In your computer, go to the download location, then run the installer. If necessary, allow the installer to make changes to your computer. **f.** Review or modify the file extraction directory, then select **OK**. **g.** After file extraction finishes, select **OK**. **h.** In your computer, go to the file extraction directory, then run the executable file (.exe).

2 Select the correct printer driver from the list, then select **Next**.

If an error occurs, resolve any possible issues by making sure that:

- Your printer is connected to your computer or network.

- The printer is on standby and is not performing any jobs.

3 Review or modify any of the available options or settings.

To ensure that any changes are saved, after modifying an option or setting, select **Apply**.

To reject any changes, select **Cancel**.

3 Maintenance Menu options

- You can adjust the units of measurement in your computer system settings.
- Available options and settings may vary depending on your printer configuration and available paper sources for printing and scanning.

Option	Details
Adjust print position	Review or modify any of the following settings for the available paper sources: **Print start position** Define the top margin start position for printing. **Center line** Define the left margin start position for printing.
Adjust Start Position	Define the top margin start position for printing.
Adjust Center Line	Define the left margin start position for printing.
Print	Specify the default values for print settings, such as Copies, Duplex, and Paper Cassette.
Adjust scan position	Review or modify any of the following settings for the available scan sources: **Scan start position** Define the top margin start position for scanning. **Center line** Define the left margin start position for scanning. **Scan end position** Define the bottom end position for scanning. This setting is available only if a document processor is installed on your printer.

Option	Details
Adjust print quality	Review or modify any of the following settings: **Drum charge setting or MC** This option appears as Drum charge setting or MC depending on your printer. Define the main charge voltage of the drum unit. • A lower value makes the print output more dense. • A higher value makes the print output less dense. **GS** Optimize image development and image transfer to suppress any ghost or double prints. • A lower value decreases the developer and transfer sensitivity. • A higher value increases the developer and transfer sensitivity. **Altitude adjustment** Specify the range of the estimated altitude of your location. **Drum refresh** If print outputs appear blurry, select this option to clean the drum unit. After drum refresh finishes, clean the transfer roller. For more information, see the *printer Operation Guide*.
Load package	Browse and select a .mtp maintenance package file. This file contains information about maintenance functions that you can modify. To get a maintenance package file or to inquire about any additional maintenance functions, contact your sales representative.

©2023 KYOCERA Document Solutions Inc.
The Kyocera logo is a trademark of Kyocera Corporation.